


WINDOW FRAME ANCHORING

The 2001 FLORIDA BUILDING CODE requires window and door assemblies to be anchored according to the manufacturer's recommendations to achieve the design pressures specified (see Section 1707.4.4 Anchorage Methods). The sketches below represent the load paths used to calculate this anchoring.

WINDOW TYPE: Awning

Load Path Sketch:



Awning Window

Anchoring Formula:

NA = Number of Anchors Required per Zone

P = Design Pressure (psf)

A1 = Area (sq. feet) per zone

FV = Fastener Shear Value (lbs.)

$$NA = A1 * P / FV$$


Example:

60" wide X 36" high
 Design Pressure = 55 psf
 FV = 180 lbs.
 A1 = 7.5 sf

$$NA = A1 * P / FV$$

$$NA = (7.5)(55)/180 = 2.3 \text{ (round up to 3)}$$

Therefore, a minimum of 3 anchors per zone are required (6 total).



7/30/2002

Lyndon F. Schmidt, P.E.
 Florida License No. 43409
 19506 French Lace Dr.
 Lutz, FL 33558